
Petrolatum Mastic - Step 2 Petrolatum Tape

Product Images



Short Description

Petrolatum mastic, 3kg litres - the 2nd step in the petrolatum pipe protection process, suited for use as a filler for voids. Used to profile irregular shapes in preparation for the application of petrolatum tape, great for use around flanges, bolts, pipe joints and valves.

Description

INSTALLATION OF PETROLATUM TAPE

RAM PETROLATUM TAPES are extremely surface tolerant and unyielding to moisture, acids, alkalis and salt solutions. RAM PETROLATUM TAPE systems utilize microcrystalline waxes which achieves excellent characteristics including high conformability, superior adhesion / amalgamation to itself and substrates whilst being user friendly to semi skilled applicators.

- 3L block
- Carton Qty: 8 blocks

Surface Preparation

Wire brush dirt, loose rust and foreign matter from surface to be protected. Surfaces should be reasonably dry. On wet surfaces use RAM Marine Primer.

Priming

Apply a thin even film of RAM Primer over the metal surface by gloved hand.

Filling

RAM Moulding Mastic should be used where necessary to improve contours at fittings to achieve a streamline contour. The wrapped fitting with the specified overlap must have no voids, air bubbles and wrinkles.

Taping

Start applying the RAM Petrolatum Tape with a full circumferential turn around the fitting and utilize a nominal 50% overlap to achieve a double thickness of tape. Apply tape ensuring firm tension and then smooth down by hand to exclude any moisture and/or water.

On each new roll of tape, underlap the new roll on previous by a minimum 100 mm.

Overwrapping

RAM High Temperature Outer Wrap should be spirally wrapped (similar to previous procedure) under tension to guarantee contact to achieve a nominal 50% overlap.

CODE	06-PM3
U.O.M	Each
Weight	2
Swatch	no_selection



Additional Information