

Tar Pad For Pavement Markers

Product Images



Short Description

Heat activated tar pad for quick and easy fixing of raised reflective pavement markers (RRPMs) or Cats Eyes to the pavement. Measures 100mm x 75mm.

Description

Ideal for installation of pavement markers, tar pads only take 90 seconds to install. Use tar pads instead of mixing messy epoxy and waiting for it to cure, or wasting unused mixtures. These tar pads cure within just 2 minutes allowing closed sections of roads to be re-opened immediately. Note these pavement marker tar pads require a gas torch - applying heat enables the tar to become soft and tacky. Simply heat the pad and stick the RRPM or pavement marker onto it. Tar pads are sold individually, each pad measures 100mm x 75mm.

Additional Information

CODE	14-TPAD
U.O.M	Each

