

3-Panel Flat Fold P2 Respirators 10/pk

Product Images





Short Description

3-Panel Flat Fold P2 Respirators 10/pk

Description

- Stored unopened boxes have a 5 year lifespan. CHECK EXPIRY DATE ON BOTTOM OF BOX BEFORE USE.
- Fit the respirator and check leak-tightness BEFORE entering the contaminated area.
- Wear the respirator for the entire duration of exposure to contaminants.
- Use the respirator in accordance with applicable health and safety regulations.
- Discard the respirator and replace with a new one if:
 - The respirator is removed in a contaminated area.
 - Excessive clogging of the respirator causes breathing difficulty or discomfort.
 - The respirator becomes damaged.
 - The smell of vapours becomes apparent. (For respirators protecting against vapours)
- Leave the contaminated area if dizziness, irritation or other distress occurs.
- Use only once, then discard. (one shift maximum)
- Keep unused respirators in their closed box and store in a dry non-contaminated area.
- All respirators must be used between -10 to +50°C.
- Installed filters can only be used for up to 8 hours according to limitations to use.
- All respirators must be used in accordance with AS/NZS1715.

Additional Information

| | |
|--------|--------------|
| CODE | 31-2PV3P |
| U.O.M | Pack |
| Swatch | no_selection |

